



# AuxBox 4102 Firmware Upgrade Instructions

**Convergent Technologies Ltd**  
Unit 07, Workstore, 19 Ormiston  
Rd, East Tamaki, Auckland

PO Box 75-337, Manurewa,  
Manukau, Auckland

Ph. 09 2671756 Fax: 09 2680395  
E-mail: [inquire@cvtech.co.nz](mailto:inquire@cvtech.co.nz)  
Home Page: [www.cvtech.co.nz](http://www.cvtech.co.nz)

## Firmware Installation Instructions

- ? Start the download by **right clicking** on the page link.
- ? Select "**Save Target As**" and save the downloaded file "**c0350301.hex**" to your hard drive by specifying "**C:**", then the "**Program Files**" folder, then the "**AuxBox**" folder. Note the location where you save it.
- ? Connect power to the AuxBox and connect the USB cable between the AuxBox and your PC.
- ? Open the AuxBox Recorder Software on your PC.
- ? In the "**SetUp**" menu, select "**Upgrade AuxBox Firmware**" (select "**Continue**" when prompted).
- ? Use the Open dialog box that appears to select the file "**c0350301.hex**" from the location where you saved it.
- ? Wait for download to complete. This will take up to 30 seconds (line count will go to about 200-300).
- ? It is recommended that you download BOTH the software and firmware when doing an upgrade to ensure all new features work correctly.